

Electronic Intelligent Controls, S.L. Passatge Garrotxa, 6 08830 Sant Boi de Llobregat Barcelona, Spain


Tel.: +34 93 652 55 21 Fax: +34 93 652 55 22 www.e-controls.es info@e-controls.es

Instruction sheet

EN

e-Room Modular 4I/5O Modbus 12V

Fan-Coil Controller for DIN-Rail Mounting with Modbus Communication



The e-Room Modular 4I/5O Modbus 12V is a fan-coil controller with remote communication, designed for DIN-rail mounting. It combines climate and lighting control functions, managing the switching on and off of both systems according to the occupancy status of a room or area, through 4 inputs and 5 outputs available on the device to perform different functions.

The device is specially designed to provide maximum comfort and optimal energy efficiency for the installation, regulating the climate to reach the level desired by the user.

The unit provides different selectable configurations depending on the type of installation and required functionality. It includes a communication bus and a power output to connect a display so that the user can manage climate control. It also includes a Modbus communication bus for remote communication with a BMS system for global building management.

Main features

- Fan-coil controller for 2-pipe and 4-pipe installations.
- Six possible configurations according to the type of installation.
- Two self-configurable dry-contact inputs: keycard/motion detector, window contact
- Two self-configurable analog inputs: water probe for mode change/door contact/ lighting pushbutton, external temperature/lighting pushbutton.
- Three relay outputs for fan-coil speed.
- Two relay outputs for valves (2/4 pipes) + room/courtesy lighting.
- Modbus RTU communication protocol with RS-485 interface for remote management through BMS.
- RS-485 interface communication bus for connection with the sensor-display.
- · Power supply from the mains.
- Configurable economy mode when the room is unoccupied (off/setpoint change).
- · Configurable actual and user setpoints for cooling and heating.
- Automatic start-up in case of temperature excess or frost risk.
- Fan-coil type configuration: 3-speed / 1-speed.
- · Configurable fan-coil locked speed when there is no demand.
- · Configurable cooling/heating setpoint in ECO mode.
- · Configurable dead band between cooling and heating.
- · Delay to switch to stand-by when the room becomes unoccupied.

Device configuration

Type of Installation	Number of Pipes	1-2	3-4	5-6	7-8	
Option 1	2	Keycard contact	Window contact	Lighting Pushbutton	T≇ Ext.	
Option 2	2	Keycard contact	Window contact	T ² Water	T# Ext.	
Option 3	4	Keycard contact	Window contact	T# Water	T# Ext.	
Option 4	2	Motion Sensor	Window contact	Door Contact	Lighting Pushbutton	
Option 5	2	Motion Sensor	Window contact	Door Contact	T# Ext.	
Option 6	4	Motion Sensor	Window contact	Door Contact	T# Ext.	
				Outputs terminals		
Type of Installation	Number of Pipes	C-1	C-II	C - III	OUT 1 (13-14)	OUT 2 (15-16)
Option 1	2	Fan-Coil Speed I	Fan-Coil Speed II	Fan-Coil Speed III	Lighting	EV HEAT/COOL
Option 2	2	Fan-Coil Speed I	Fan-Coil Speed II	Fan-Coil Speed III	Lighting	EV HEAT/COOL
Option 3	4	Fan-Coil Speed I	Fan-Coil Speed II	Fan-Coil Speed III	EV HEAT	EV COOL
Option 4	2	Fan-Coil Speed I	Fan-Coil Speed II	Fan-Coil Speed III	Lighting	EV HEAT/COOL
Option 5	2	Fan-Coil Speed I	Fan-Coil Speed II	Fan-Coil Speed III	Lighting	EV HEAT/COOL
				Fan-Coil Speed III	EV HEAT	EV COOL

Installation instructions

The device is designed for mounting in cabinets with a standard DIN EN 50 022. It should not be installed on shelves, behind curtains, near or above heat sources, or exposed to direct sunliaht.

Important:

- Install the device in the electrical panel, keeping the very low voltage signal wiring (inputs) separate from the low voltage wiring (outputs).
- Use shielded cable for the communication channel with the BMS.
- Always follow the type of wiring indicated in the installation diagram.

Caution:


- · Before installing, uninstalling, or cleaning the device, ensure that there is no voltage in the mains cables or near the device.
- Do not cut, splice, or coil the mains cables connected to the device.
- Do not handle connections with wet hands.
- Do not open, drill, or modify the product.
- Keep the device and cables away from moisture and dust.
- Clean only with a slightly damp cloth using water.

Installation steps:

- Disconnect the power supply to the electrical panel.
 Insert the device onto the DIN rail, placing the black latch at the bottom; pull the latch down, press the device until it snaps into place, and release the latch to secure it.
- 3. Verify that the panel wiring follows the construction mounting diagram.
- 4. Connect the cables to the terminals according to the diagram and attach them to the device.
- 5. Restore the power and check the operation.
- 6. Close the electrical panel.

Installation drawing

Install electrical protections and required cabling according to the standards of every country.



In 2 pipes configuration, OUT1 is used for lighting control (courtesy lighting or global room lighting) and OUT2 for valve control (Heat/Cool).

Device initialization

When power is applied to the controller, the unit takes 30 seconds to initialize. During the first 5 seconds, the power LED blinks red; from 6 to 30 seconds it stays solid red. After 30 seconds, the LED turns solid green.

Technical features

Power Supply

Operating Voltage
Maximum power consumption
BMS Communication (BMS RS-485 connector)
Interface
Terminals
Protocol Modbus RTU
Configurable baud rate
Modbus configuration
Display Interface (RS-485 e-Room Bus connector)
Interface
Terminal +24V output voltage
Terminal +24V output current
Protections
Open circuit voltage
Sourt-circuit current
Input impedance
Analog/Digital Inputs (IN3, IN4)
Configuration in Digital mode
Open circuit voltage
Sourt-circuit current
Input impedance >25 KG
Configuration in Analog mode
Type
Characteristics
Measurement range
Resolution
Input impedance >68 KG
Relay Outputs for Fan-Coil Speeds (FC I, FCII, FCIII), and outputs OUT1, OUT2
Contact type Potential-free rela
Maximum operating voltage
Maximum current
Front LED Indicator (POWER)
Device unpowered LED o
Device powered
Reset / Initialization
Communication failure with Display
Operating Conditions
Temperature .0°C to +50°C (32°F to 104°F Storage temperature -20°C to +85°C (-4°F to +185°F
Storage temperature
Operating
Storage
Mechanical Characterístics
Mounting type
Dimensions
Weight
Color
Cable cross-section. 0,5 mm2 to 2,5 mm.
Protection degree
Electrical safety
Product family standards
Automatic electrical control devices for household and similar use EN 60730-1:201
Complance Directives
CE Marking
Security
Standard
EMC
Emissions EN 61000-6-
Immunity EN 61000-6-
Ordering numbers

Ordering numbers

The package of this product is considered as industrial packaging intended for professional use only. The manufacturer is not responsible of the incorrect installation or use of the product. Specifications are subject to change without notice

