e-Touch Flexi 2RV-6P

Electronic Intelligent Controls, S.L. Passatge Garrotxa, 6

08830 Sant Boi de Llobregat Barcelona, Spain Fax: +34 93 652 55 22

Tel.: +34 93 652 55 21

www.e-controls.es info@e-controls.es

Instruction sheet

V



Multifunctional touch switch with 2 vertical buttons, 6 touch zones and 2 led indicators

e-Touch Flexi is a multifunctional touch switch product family for lighting control, curtains and motorized blinds control or for any other control requirement in an installation. The touch keypads are completely customizable and it is possible to define the design of any pushbutton and any touch zone of the panel using the e-Touch Creator web page in www.e-controls.es, being able to combine any colour for the pushbutton with icons or texts that clearly define each touch

The e-Touch Flexi 2RV-6P model consists of two vertical buttons with 3 touch zones on each. that can be configured with any control function. Each button has one led indicator to signal different functions.

e-Touch Flexi is combined with any bus coupling unit of the e-Bus Coupling family products, that provides the necessary control for the desired communication protocol and is configured through the EConfigurator APP available for Android in Google Play Store.

Product description

The e-Touch Flexi touch switch allow to perform any lighting control function in an installation. like switch on, switch off, light dimming and scene control, with a simple press on any touch zone. Control of motorized curtains or motorized blinds is also possible through additional devices for

The e-Touch Flexi panels are connected through a connector located on the back side, to a bus designs: coupling unit, called e-Bus Coupling, that provides the communication protocol to the building management system. Different bus coupling units are available for the most used communication protocols for building automation, thus being able to combine any touch keypad with any bus

Keypad customization tailored to each project

Through the e-Touch Creator website in www.e-controls.es, it's possible to define the aesthetic of each of the pushbuttons, being possible to choose an icon or a text for each touch zone as well as the colour, for the pushbutton background and for the icon or text. It's also possible to

add images or pictures for every touch zone, making the device a completely flexible product and adaptable to any project.

OFF

Once the touch switch is finished, it's possible to send the design through a form to E-Controls for printing, or also download the design to print by anyone. The following examples show different







Function settings for each touch zone

This touch switch has 2 vertical buttons with three touch zones on each, that can be configured with the desired function. Depending on the type of bus coupling unit selected, the touch switch can do some functions or others, based on the protocol selected and the functions defined in the communications standard of every protocol.

In order to properly configure each touch zone it is necessary to know the number of each pushbutton. The following image shows the figures that define each touch zone:

- If a DALI 2 bus coupling unit ref. BC.080001-001 or BC.582001-001 is selected to operate with a DALI controller, it is necessary to use manufacturer tool of the DALI controller to do the configuration of each pushbutton function. To do this, each pushbutton number will be used to assign to each instance of the DALI bus.
- If a MASTER bus coupling unit is selected, like the model e-Bus Coupling DALI Master ref. BC.581002-001 or the model e-Bus Coupling 0-10V ref. BC.501001-001, it is necessary to use the APP EConfigurator tool to configure the functions of each touch zone.

Touch switch LED indicators functions

This touch switch has one led indicator on each button, so two in total, that performs different functions depending on the type of bus coupling unit used.


The functions available for the Led indicators are:

- Pressing a key: When pressing any of the three touch zones of a button, the touch switch front led indicator of the key lights up indicating that the pushbutton has been pressed.
- Correct initialization of the device: When de device powers up, the led indicators starts a switch on/off sequence from left to right, indicating that the device is properly configured.
- Cleaning mode: When entering in cleaning mode, the led indicator nr. 1 flashed briefly every second during the 60 seconds cycle that lasts the cleaning mode.
- Configuration conflict: The led indicators starts a switch on/off sequence opposite to the previous one, this means, from right to left, indicating that the bus coupling unit

has been previously configured with another touch switch model. In this case it must be

reconfigured again for this touch switch model

- Installation error: If a touch switch is configured for one bus coupling unit model and afterwards is connected to another bus coupling unit model, the led indicator nr. 1 will flash rapidly during 10 seconds at the moment of powering the device or every time that a touch zone is pressed, indicating an installation error. In this case, it must be reconfigured again or has to be connected to the correct bus coupling unit.
- Receiving a "Wink" command: The led indicator nr. 1 blinks at a rate of one second during 30 seconds. This case is relevant for a DALI bus coupling unit configured through a DALI controller.



Proximity and brightness sensor

The touch switch includes a proximity and brightness sensor that provides different functions:

- · Auto switch off scene led: Depending on the bus coupling unit, it is possible to configure the led indicators to stay switched on to signal scenes or states. For this case it is possible to configure the led indicators to turn off automatically when the room becomes dark, to avoid disturbing them.
- · Cleaning mode function: The cleaning mode function allows you to lock the operating of the touch switch temporarily in order to clean the panel. To do this, the proximity sensor must be covered for 5 seconds with the finger until the led indicator 1 flashes. In this state the touch switch is locked during 60 seconds so it can be cleaned without sending commands.

General touch switch configuration functions

Through the APP EConfigurator of E-Controls and the NFC proximity wireless data transfer technology, it is possible to configure the device. To do this, download the APP from Google Play Store and install it in a mobile phone with an Android operating system.

The configuration of the touch switch can be done without powering the device, and even without removing it from the packaging, making the configuration process extremely easy.

The configuration parameters available on the device are:

- 1. Auto switch off scene leds: Enable / disable the auto switch off of the led indicator when the room becomes dark. By default this function is enabled.
- 2. Cleaning mode: Enable / disable this function. By default this function is enabled.
- 3. Led intensity: Brightness level front led intensity can be adjusted between 0 and 100%. By
- 4. Touch switch sensitivity pushbuttons: Adjust the sensitivity of the touch zones between 4 possible values; low, medium, high, very high, By default is at high,

NOTE: In case if configuring the device powered, when bringing the phone near the device, some unwanted pushbutton press may be detected that interacts with the installation.

Product installation

NOTE: For the installation the bus coupling unit, read the instruction sheet of the device selected. Caution Disconnect the power supply of the bus coupling unit to which the touch switch will be

- Assemble the plastic frame on the touch switch paying attention that the ventilation slots are
- in the lower and upper left side.
- Clip the touch switch e-Touch Flexi into the holes of the front connector on the bus coupling unit, and press until the frame will be firmly fixed to the wall and pressed by the keypad.

- Apply supply power to the device and check the front led indicator flashes.
- Configure the device according to the bus coupling unit selected.
- Remove the front protective film of the device. Touch switch + bus coupling unit selected (see note)

Brightness sensor

Disconnect the device from the power supply before mounting or moving it.

- Do not leave cables peeled or turned around the device.
- · Do not connect the device with the hands wet.
- · Do not open or hole the device.
- Keep the device and cables away from humidity and dust.
- · Clean the front cover with a water moisture soft cloth.

Technical features

with e-Bus Coupling 0-10v (BC.501001-001)	VVa
Nith e-Bus Coupling KNX (BC.090001-001)	Med
NOTE: First value: Current consumption with all sensors active, the led permanently turned on	Dir
and communicating. Second value: Current consumption with all sensors active, all led perma-	We
nently turned on and communicating (in devices with communication bus). In DALI Master and 0-10V devices it is only possible to switch on one led at the same time.	Fre
ouch switch	Co
	Pro
Type	Tem
Number of buttons	
Number of touch zones	Op Sto
	Hun
Custom design though e-Touch Creator website	
Dindicators	Op Sto
Quantity	
Colour	Star
unctions LED brightness dimmable 0-100%	Au
emperature sensor	CEc
Sensor type Digital	Lov
Resolution	Ele
Measuring range	Ma
umidity sensor (optional)	Seci
Sensor type Digital	Sta
Resolution	IEC
Measuring range	EMC
ireless communication	Em
Fechnology	lm
Standard	
Reading speed	C

Measuring range
Resolution
Bandwidth
Wavelength peak
Mechanical features
Dimensions (with frame)
Weight
Installation
Front panelMethacrylate
Colour
Protection degree (assembled)
Temperature
Operating
Storage
Humidity (no condensation)
Operating
Storage
Standards
Automatic electrical controls for household and similar use EN 60730
CE conformity
Low voltage directive
Electromagnetic Compatibility Directive
Marking
Security
Standard
IEC protection
EMC [*]
Emission
Immunity

Sensor type. Visible radiation silicon photodiode

Ordering numbers

e-Touch Flexi 2RV-6P White, touch switch 2 vertical buttons, 6 touch zones, 2 leds, white . . . TP.020600-000 e-Touch Flexi 2RV-6P Black, touch switch 2 vertical buttons, 6 touch zones, 2 leds, black . . . TP.020602-000

The package of this product is considered as industrial packaging intended for professional use only. The manufacturer is not responsible of the incorrect installation or use of the product. Specifications are subject to change without notice.

